

Steinhalt Grundkästen															
KKNF Nr	3 - Barby			5 - Bautzen			7 - Belgard			9 - Berent			11 - Berlin		
	G	R	B	G	R	B	G	R	B	G	R	B	G	R	B
1					2		2	2		2	4		4	4	
3	4			4	4		8	6		8	8		12	10	
4	2	2		2	2		2	4		2	8		2	8	
5					2			2		2	2		2	2	
8								4		8	8		8	8	
9											8			8	
11								4			4			4	
12	4			6	4		8	4		8	4		8	6	
13														8	
14	2	2		4	2		4	6		8	6		8	8	
15		4			4		2	4		4	4		4	8	
16														8	
18							2			2			2		
22											4			4	
23		2			4			4			4			4	
25	3	2		4	6		4	6		8	6		8	6	
26											4			8	
27					2			4			4			6	
28											4			4	
29														4	
30							4			8			8		
31											4			4	
33	2			4	2		4	4		4	4		4	4	
34											4		4	4	
35							4			4			4		
36	4	4		6	6		8	8		8	10		8	10	
38								4		4	8		4	16	
39				4			4			4	12		4	12	
42							4			4			4		
45		1			1			1			1			1	
48				1			1	1		1	1		1	1	
49				1			1	1		1	1		1	1	
52														1	
71											2		8		2
73					4			4			10			12	
78												4			4
90															4
93												2			2
139													4	8	
140													8	8	
Subges.	21	17	0	36	45	0	62	73	0	90	137	8	124	196	12
Gesamt		38			81			135			235			332	

Metallteile Grundkästen					
MT-Nr	3	5	7	9	11
5	4	8	8	8	8
6			2	6	6
7	2	4	6	6	6
8			4	12	12
9	4	8	12	12	12
10	8	16	20	20	20
12			2	4	4
13			2	4	4
14			2	4	4
15					6
16					6
17					3
18					2
19					12
20				4	12
26					1
Gesamt	18	36	58	80	118
22			4	8	8
Schr.zhr	1	1	1	1	1
Schraube	16	32	44	44	44

*) Schraubenzieher Nr 11, 23 oder 184
 **) Schrauben in Blechdose